


### Removal (Convertible doors only)

The window frame is fastened by one screw at the lock side and two screws at the hinge side which are accessible from inside as shown. The lower fastening screws are located in the bottom of the door and accessible from underneath. After removing these screws lift out frame.



Arrows indicate the fastening screws for the window frame

- ① Screws for door lock (inside of door)
- ② Screws for door lock (in closing edge)
- ③ Stop screw for Convertible window

